



Procedure for Using Grease Gun Sleeves

1. Remove the pump mechanism, grease, and plunger from the grease gun.
2. Clean the outside barrel of the grease gun with a clear solvent and dry.
3. Apply desired grease label or color code labels to the barrel of the grease gun.
4. Slide the shrink tubing over the barrel and center lengthwise.
5. Using a high-temperature heat gun or infrared heater set at 90°C (194°F), heat the shrink tubing evenly by concentrating heated air along the length until it starts shrinking.
6. Move the heat gun along the shrink tubing until it has shrunk to a smooth surface on the barrel of the grease gun. This might take up to five minutes of heating.

Grease Gun Sleeves (Item #050) are a product of Strategic Work Systems.

To order, go to www.thevisualmachine.com or order by phone/fax: (864) 862-0446.